



WAGON WHEEL

16-pc. Starter Set	14.00	94l—12 oz. tumbler75
94a—10 oz. creamer	1.00	94p—16" platter	5.00
94b—10 oz. sugar with lid	1.00	94q—13" platter	2.50
94c—5 oz. cup75	94qd—2 sec. service dish, 13"	2.50
94e—5" saucer75	94t—6 cup tea pot	2.00
94d—2 qt. pitcher	2.00	94v—2 qt. baker	2.50
94f—9" plate	1.50	94w—3 qt. baker	3.50
94fc—7 sec. lazy susan, 15"	7.50	94x—16 oz. chili, soup, or cereal60
94fl—10½" dinner plate	1.60	94xl—24 oz. service bowl	1.00
94g—7" plate80	94xo—5 oz. dessert50
94h—salt and pepper, pair	1.00	510—individual sugar50
94j—2 cup tea pot	1.20	560—individual creamer50
94m—16 oz. mug	1.00	454—candle holder ash tray	1.50
94n—1 qt. service dish	1.50		

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD