




5V-BAKER 2 QT.—3.00




5F-PLATE 10"^{1.90}—1.80


5FS-9" PLATE—1.50

5G-PLATE 7 1/2"—1.25

5GS-PLATE 6 1/2"—1.00



5W-BAKER 3 QT.—4.00



5NS-9" VEGETABLE—2.00



5LC-6 OZ. JUICE—.75



5DC-DEMITASSE CUP—.65

5DE-DEMITASSE SAUCER—.65



5CL-MUG 12 OZ.—1.00



5A-12 OZ. CREAMER—1.00




5B-SUGAR WITH LID—1.50



5C-8 OZ. CUP—.75


5E-5 1/2" SAUCER—.75




5HS-SALT & PEPPER—1.50



5WL-5 QT. BAKER—5.00



5FC-15" CHOP PLATE—7.00



5P-17" PLATTER—5.00

5Q-13" PLATTER—2.50



5L-12 OZ. TUMBLER—.75




5M-MUG 16 OZ.—1.20



5DB-6 OZ. SUGAR—.75




5DA-6 OZ. CREAMER—.75



5XL-BOWL 20 OZ.—1.25

5X-CEREAL 14 OZ.—1.00


5XS-FRUIT 9 OZ.—.80



5QD-13" DIVIDED BOWL—2.50




5TL-TEAPOT, 12 CUP—4.00



5QS-13" PLATTER—2.00

5PS-9" TRAY—1.25



5ND-9" CHEESE DIP—2.50




5N-4 1/2 QT. BOWL—5.00



5T-6 CUP TEAPOT—2.50



5D-3 QT. PITCHER—3.50



5S-20 OZ. GRAVY BOAT—1.50