



LAZYBONES

16-pc. Starter Set	14.00	88—1½ qt. water jug	2.00
4a—8 oz. creamer	1.00	4m—16 oz. Mug	1.00
4b—8 oz. sugar	1.00	4n—service bowl	1.25
4c—5 oz. cup75	4p—platter	2.50
4d—2 qt. pitcher	2.00	4s—bone dish80
4e—5" saucer75	4v—1½ qt. baker	2.50
4f—10" plate	1.60	4w—3 qt. baker	3.50
4g—7" Plate80	4x—16 oz. bowl80
4h—salt and pepper	1.00	4xu—covered bowl	1.50
4k—covered butter dish	1.50	4z—6¼" salad bowl	1.00
5l—12 oz. tumbler75	231—service dish	2.00
80—2 qt. pitcher	2.00	4qd—2 section serving dish	2.50
86—2 qt. water jug	2.00	4y—spoon holder, 6"	1.00
87—1 qt. pitcher	1.50		

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD, AND CLAY BLUE