


*4K—BUTTER DISH—2.50



4F—10" PLATE—2.25

4G—7" PLATE—1.10

4E—5" SAUCER—.90



4S—6½" BONE DISH—1.25



*4X—16 OZ. CEREAL—1.25



*5L—12 OZ. TUMBLER—1.10



*5LC—6 OZ. JUICE—.90



4C—CUP—1.00



*4Y—6" SPOON HOLDER—1.00



4H—SALT & PEPPER—1.50



4A—8 OZ. CREAMER—1.25



4B—SUGAR WITH LID—1.75




4M—18 OZ. MUG—1.50



4Z—6" SOUP—1.25



*4V—2 QT. BAKER—4.00




4P—13" PLATTER—3.50



4N—24 OZ. VEGETABLE—1.50



*4W—3 QT. BAKER—5.00



4QD—11" DIVIDED BOWL—3.00




*214—12" SERVICE BOWL—2.50



*4SC—11 OZ. SOUP CUP—1.50



*BP—6 OZ. BEAN POT—.90



*231—11" SERVICE BOWL—2.50



4XL—24 OZ. SALAD OR GUMBO—1.50



*818—5 SECTION LAZY SUZETTE ON BALL BEARING BASE—12"—7.50



4D—2 QT. PITCHER—4.00