


\*4K—BUTTER DISH—2.50



4F—10" PLATE—2.50

4G—7" PLATE—1.25

4E—5" SAUCER—1.20



\*5L—12 OZ. TUMBLER—1.20



\*5LC—6 OZ. JUICE—1.00



5CC—5 OZ. TEACUP—1.20



\*4X—16 OZ. CEREAL—1.50




4C—CUP—1.20



\*4Y—6" SPOON HOLDER—1.00



4H—SALT & PEPPER—1.75



4A—8 OZ. CREAMER—1.50



4B—SUGAR WITH LID—2.00




\*4M—18 OZ. MUG—1.80




4Z—6" SOUP—1.25



\*4V—2 QT. BAKER—4.50




4P—13" PLATTER—3.50




\*4N—24 OZ. VEGETABLE—1.50



\*4W—3 QT. BAKER—6.00



4QD—11" DIVIDED BOWL—3.50



\*214—12" SERVICE BOWL—2.50



\*4SC—11 OZ. SOUP CUP—1.50




\*BP—6 OZ. BEAN POT OR CUSTARD—1.00




\*201—9" BOWL—2.00



4XL—24 OZ. SALAD OR GUMBO—1.50



\*818—5 SECTION LAZY SUZETTE ON BALL BEARING BASE—12"—7.50



\*4D—2 QT. PITCHER—4.00