




\*5V—2 QT. BAKER/BEAN POT—4.50




5F—10" PLATE—2.50

5FS—9" PLATE—2.00

5G—7" PLATE—1.50



\*5W—3 QT. BAKER/BEAN POT—6.00



\*5NS—9" VEGETABLE—2.50



\*5CC—5 OZ. TEACUP—1.25



\*5DC—DEMITASSE CUP—1.25

\*5DE—DEMITASSE SAUCER—1.25



\*5A—12 OZ. CREAMER—1.75



\*5CL—12 OZ. MUG—1.50



\*5B—SUGAR WITH LID—2.25



5C—CUP—1.35


5E—5½" SAUCER—1.25



\*5HS—SALT & PEPPER—2.00



\*5N—4½ QT. BOWL—8.50




5FC—15" CHOP PLATE—10.00



\*5M—16 OZ. MUG—2.00



\*5L—12 OZ. TUMBLER—1.50



5P—17" PLATTER—8.50


5Q—13" PLATTER—3.50



\*5DB—6 OZ. SUGAR—1.50




\*5DA—6 OZ. CREAMER—1.50



5XL—20 OZ. BOWL—1.50

5X—14 OZ. CEREAL—1.25

5XS—9 OZ. FRUIT—1.00




\*5QD—13" DIVIDED BOWL—3.50



\*5TL—12 CUP TEAPOT—6.00



\*218—12" BOWL—3.50



\*5QS—13" PLATTER—2.50

\*5PS—9" TRAY—1.50

\*6P—11" PLATTER—2.00



5S—20 OZ. GRAVY BOAT—2.50



\*6T—6 CUP TEAPOT—4.00



\*6J—2 CUP TEAPOT—2.50



5D—3 QT. PITCHER—5.00

THIS PAGE AVAILABLE IN BROWN SATIN, DESERT GOLD, PRAIRIE GREEN & WOODLAND MOSS, EXCEPT WHERE NOTED\*.

\* AVAILABLE IN ALL COLORS—ADD 50% FOR FLAME

SIZES ARE APPROXIMATE AND MAY VARY SLIGHTLY.