


\*4K—BUTTER DISH



4F—10" PLATE

4G—7" PLATE

4E—5" SAUCER



\*5CC—5 OZ. TEACUP



\*4X—14 OZ. CEREAL



\*5L—12 OZ. TUMBLER



\*5LC—6 OZ. JUICE



4C—CUP



\*4Y—6" SPOON HOLDER



\*4H—SALT & PEPPER



4A—8 OZ. CREAMER



4B—SUGAR WITH LID



\*4M—18 OZ. MUG



\*243—BONE DISH—6 1/2"



\*4V—2 QT. BAKER/BEAN POT  
\*4V/W—BAKER/W WARMER SET

4AB—CREAM & SUGAR SET



\*4N—24 OZ. VEGETABLE




\*4P—13" PLATTER



\*224—8" ROUND BOWL



\*4W—3 QT. BAKER/BEAN POT  
\*4W/W—BAKER/W WARMER SET



\*4QD—11" DIVIDED BOWL



\*201—9" BOWL



\*BP—6 OZ. BEAN POT OR CUSTARD



\*M2—18 OZ. STEIN



\*4D—2 QT. PITCHER



\*4SC—11 OZ. SOUP CUP



\*4XL—24 OZ. SALAD OR GUMBO

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD, BROWN SATIN AND ROBIN EGG BLUE, EXCEPT WHERE NOTED\*

\*AVAILABLE IN ALL COLORS — ADD 50% FOR FLAME

SIZES ARE APPROXIMATE AND MAY VARY SLIGHTLY.