

80 SET



80—8 QT. PITCHER 8.50 5L—12 OZ. TUMBLER 3.50

C12—7 OZ. MUG 3.00



82 SET (82—6 CUP CARAFE & LID 82W—WARMER) 18.00

Gift Sets



6T—6 CUP TEAPOT 8.50 5DA—6 OZ. CREAMER 3.00
WA3—6" WARMER W/CANDLE 4.50 5DB—6 OZ. SUGAR 3.00


5D SET



5D—3 QT. PITCHER 10.00 5M—16 OZ. MUG 4.00



6S—TWO-SPOUT GRAVY 6.00
5PS—9" PLATTER-TRAY 3.50
6S/ST—TWO-SPOUT GRAVY/W TRAY 9.50



SOUP AND SANDWICH SET
4SC—11 OZ. SOUP CUP 3.50
6P—11" PLATTER-TRAY 4.00




COFFEE AND DESSERT SET
5PS—9" PLATTER-TRAY 3.50
C2—10 OZ. MUG 3.00
(or choose your own style
Mug — See Pg. 9)



6J SET 15.00

6J—2 CUP TEAPOT 6.00
504—INDIVIDUAL SUGAR 2.50
553—INDIVIDUAL CREAM 3.00
6P—11" PLATTER TRAY 4.00



5TL/W—TEAPOT & WARMER SET 18.50
5TL—12-CUP TEAPOT 12.00
WA1—WARMER 7.00



26 SET— 50.00
RINGED CANNISTER SET
26F—17.00
26S—13.00
26C—11.00
26T—10.00
26F—FLOUR, COOKIES, CORN MEAL 26S—SUGAR
26C—COFFEE 26T—TEA



26G—SUGAR/GREASE 8.50 26H—SALT & PEPPER 6.00
4-PIECE SET/BOXED 14.50



26DC SET 22.00
26D—1 QT. PITCHER 6.00 26DC—3 OZ. JUICE 3.00
91—TRAY 4.25



5LC SET 22.00
81—1 QT. PITCHER 6.00 5LC—6 OZ. JUICE 3.00
91—TRAY 4.25