



\*5V—2 QT. BAKER/BEAN POT—8.50  
\*5V/W—BAKER/W WARMER SET—15.00




\*5W—3 QT. BAKER/BEAN POT—12.00  
\*5W/W—BAKER/W WARMER SET—18.50



\*5N—4½" QT. BOWL  
15.00




\*5XL—20 OZ. BOWL —3.50  
\*5X—14 OZ. CEREAL —3.00  
\*5XS—9 OZ. FRUIT —2.50



\*218—12" BOWL —7.00




\*6S—TWO SPOUT GRAVY —6.00




5.00  
5F—10" PLATE 3.50  
3.50  
5FS—9" PLATE  
5G—7" PLATE 3.00




\*5NS—9" VEGETABLE 4.25




5FC—15" CHOP PLATE 20.00



5P—17" PLATTER —15.00 \*5Q—13" PLATTER —7.00



\*5QD—13" DIVIDED BOWL —7.00



5QS—13" PLATTER —4.50 \*5PS—9" TRAY —3.50

\*6P—11" PLATTER 4.00



\*6T—6 CUP TEAPOT—8.50



\*6J—2 CUP TEAPOT  
6.00



\*5M—16 OZ. MUG  
4.00




\*5CC—5 OZ.  
TEACUP  
2.50



5C—CUP—3.00  
5E—5½" SAUCER  
2.50



\*5LC—6 OZ.  
JUICE—3.00



\*5H—SALT & PEPPER  
4.25



\*5L—12 OZ.  
TUMBLER—3.50



\*5DB—6 OZ.  
SUGAR  
3.00



\*5DA—6 OZ.  
CREAMER  
3.00



\*5TL—12 CUP TEAPOT —12.00



\*5D—3 QT. PITCHER  
11.00

\*5AB—CREAM & SUGAR SET  
7.00

\*5A—12 OZ. CREAMER 3.00



\*5B—SUGAR WITH LID 4.50

THIS PAGE AVAILABLE IN BROWN SATIN, DESERT GOLD, PRAIRIE GREEN & AUTUMN YELLOW EXCEPT WHERE NOTED\*.

\*AVAILABLE IN ALL COLORS—ADD 50% FOR FLAME.

SIZES ARE APPROXIMATE AND MAY VARY SLIGHTLY.

Dinnerware Not Available in Terra Cotta.