


*4K—BUTTER DISH
6.50



4F—10" PLATE 6.00
4G—7" PLATE 3.50
4E—5" SAUCER 2.75



*5CC—5 OZ. TEACUP
2.75



*4X—14 OZ. CEREAL
3.25



*5L—12 OZ.
TUMBLER
3.75



*5LC—6 OZ.
JUICE
3.25



4C—CUP
3.25



*4Y—6" SPOON HOLDER
3.00



*4H—SALT & PEPPER
4.75



*4SC—11 OZ. SOUP CUP
3.75



9.25 *4V—2 QT. BAKER/BEAN POT
16.50 *4V/W—BAKER/W WARMER SET



4A—8 OZ. CREAMER
3.25



4B—SUGAR WITH LID
5.00



*4M—18 OZ. MUG
4.50



*4N—24 OZ. VEGETABLE
4.75



*4P—13" PLATTER
7.75



*M2—18 OZ. STEIN
4.50



*224—8" ROUND BOWL
6.50



13.25 *4W—3 QT. BAKER/BEAN POT
20.50 *4W/W—BAKER/W WARMER SET



*4QD—11" DIVIDED BOWL
7.75



*201—9" BOWL
4.75



*242
CORN DISH
2.50



*X0—3 OZ.
SINGLE SERVING BOWL
1.50



*BP—6 OZ. BEAN POT
OR CUSTARD
2.75



*4XL—24 OZ. SALAD
OR GUMBO
3.75



*243—6½" CRESCENT SALAD
2.50



*244—INDIVIDUAL
VEGETABLE BOWL
2.50



*4D—2 QT. PITCHER
9.25

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD, BROWN SATIN AND ROBIN EGG BLUE, EXCEPT WHERE NOTED*

*AVAILABLE IN 8 COLORS — ADD 50% FOR FLAME

Dinnerware Not Available in Terra Cotta.

SIZES ARE APPROXIMATE AND MAY VARY SLIGHTLY. Page 25