


\*4K—BUTTER DISH  
6.50



4F—10" PLATE 6.00  
4G—7" PLATE 3.50  
4E—5" SAUCER 2.75



\*5CC—5 OZ. TEACUP  
2.75



\*4X—14 OZ. CEREAL  
3.25



\*5L—12 OZ.  
TUMBLER  
3.75



\*5LC—6 OZ.  
JUICE  
3.25



4C—CUP  
3.25



\*4Y—6" SPOON HOLDER  
3.00



\*4H—SALT & PEPPER  
4.75



\*4SC—11 OZ. SOUP CUP  
3.75



9.25 \*4V—2 QT. BAKER/BEAN POT  
16.50 \*4V/W—BAKER/W WARMER SET



4A—8 OZ. CREAMER  
3.25



4B—SUGAR WITH LID  
5.00



\*4M—18 OZ. MUG  
4.50



\*4N—24 OZ. VEGETABLE  
4.75



\*4P—13" PLATTER  
7.75



\*M2—18 OZ. STEIN  
4.50



\*224—8" ROUND BOWL  
6.50



13.25 \*4W—3 QT. BAKER/BEAN POT  
20.50 \*4W/W—BAKER/W WARMER SET



\*4QD—11" DIVIDED BOWL  
7.75



\*201—9" BOWL  
4.75



\*242  
CORN DISH  
2.50



\*XO—3 OZ.  
SINGLE SERVING BOWL  
1.50



\*BP—6 OZ. BEAN POT  
OR CUSTARD  
2.75



\*4XL—24 OZ. SALAD  
OR GUMBO  
3.75



\*243—6½" CRESCENT SALAD  
2.50



249 TACO HOLDER  
BOXED 2 PER BOX 10.00  
Not Available in Flame



\*4D—2 QT. PITCHER  
9.25

THIS PAGE AVAILABLE IN PRAIRIE GREEN, DESERT GOLD, BROWN SATIN AND ROBIN EGG BLUE, EXCEPT WHERE NOTED\*