




9.25 80—2 QT. PITCHER 5L—12 OZ. TUMBLER 3.75

# Gift Sets

82C SET 33.00  
(CARAFE, WARMER,  
4 C12 MUGS)



82 SET (82—6 CUP CARAFE & LID 82W—WARMER) 20.00



6T—6 CUP TEAPOT 9.25 5DA—6 OZ. CREAMER 3.25  
WA3—6" WARMER W/CANDLE 5.00 5DB—6 OZ. SUGAR 3.25



12.50 5D—3 QT. PITCHER 5M—16 OZ. MUG 4.50



6S—TWO-SPOUT GRAVY 6.50  
5PS—9" PLATTER-TRAY 3.75  
6S/ST—TWO-SPOUT GRAVY/W TRAY 10.00



SOUP AND SANDWICH SET  
4SC—11 OZ. SOUP CUP 3.75  
6P—11" PLATTER-TRAY 4.50



COFFEE AND DESSERT SET  
3.75 5PS—9" PLATTER-TRAY  
C2—10 OZ. MUG 3.25  
(or choose your own style  
Mug — See Pg. 9)



6J SET 16.50

6J—2 CUP TEAPOT 6.50  
504—INDIVIDUAL SUGAR 2.75  
553—INDIVIDUAL CREAM 3.25  
6P—11" PLATTER TRAY 4.50



5TL/W—TEAPOT & WARMER SET 20.00  
5TL—12-CUP TEAPOT WA1—WARMER  
13.00 7.50



26 SET— 55.00  
RINGED CANNISTER SET

26F—FLOUR, COOKIES, CORN MEAL 18.50 26S—SUGAR 14.25 26C—COFFEE 12.00 26T—TEA 11.00



26G—SUGAR/GREASE 9.25 26H—SALT & PEPPER 6.00  
26GH—4-PIECE SET/BOXED 15.00



26DC SET  
24.00

26D—1 QT. PITCHER 6.50 26DC—3 OZ. JUICE 3.25  
91—TRAY 4.75



5LC SET  
24.00

81—1 QT. PITCHER 6.50 5LC—6 OZ. JUICE 3.25  
91—TRAY 4.75