


TRAYS SUITABLE FOR RELISH, NUTS, JELLIES, SALADS AND CANDY



T9
7" SHELL BOWL 3.75
204A—DOGWOOD TRAY 3.25
No Flame 3.25
473—6½" SHELL TRAY



223—6" FOUR LEAF CLOVER 3.50
83—12" Division Relish Dish 6.50
225—7" LEAF TRAY 3.50
Not Available in Flame or Terra Cotta.



818—12" Lazy-Susan with Ball Bearing Base 22.50
Not Available in Flame or Terra Cotta


5QS—13" Platter 5.00
(No Flame or Terra Cotta)
6P—11" Platter 4.50
5PS—9" Tray 3.75
No Terra Cotta



T10—12" SHELL BOWL 17.50
T9—7" SHELL BOWL 3.75
(Center piece or Salad set)
(No Terra Cotta or Flame)



222—12" CORNUCOPIA No Flame 10.00
57—7" CORNUCOPIA 5.50



819—12" Egg Plate 15.00
Not Available in Flame or Terra Cotta




10.00
809 - 9½" EGG PLATE
Not Available in Flame or Terra Cotta



Not Available in Flame or Terra Cotta.

808 Relish Dish 15.00



Not Available in Flame or Terra Cotta.

227—17" LEAF TRAY 20.00

225—7" LEAF TRAY 3.50

226—11" LEAF TRAY 6.50



No Terra Cotta

7.50
WA1—8" Warmer w/Candle
WA3—6" Warmer w/Candle 5.00