



10.00 80—2 QT. PITCHER 5L—12 OZ. TUMBLER 4.00

Gift Sets

82C SET 34.00
(CARAFE, WARMER,
4 C12 MUGS)



82 SET (82—6 CUP CARAFE & LID 82W—WARMER) 20.00



6T—6 CUP TEAPOT 10.00 5DA—6 OZ. CREAMER 3.50
WA3—6" WARMER W/CANDLE 5.00 5DB—6 OZ. SUGAR 3.50



12.50 5D—3 QT. PITCHER 5M—16 OZ. MUG 5.00



6S—TWO-SPOUT GRAVY 7.00
5PS—9" PLATTER-TRAY 4.00
6S/ST—TWO-SPOUT GRAVY/W TRAY 11.00



SOUP AND SANDWICH SET
4SC—11 OZ. SOUP CUP 4.00
6P—11" PLATTER-TRAY 5.00



SJ - 6 1/2"
Spoon
Jar - 7.00



6J SET 18.50

6J—2 CUP TEAPOT 7.00
504—INDIVIDUAL SUGAR 3.00
553—INDIVIDUAL CREAM 3.50
6P—11" PLATTER TRAY 5.00



5TL/W—TEAPOT & WARMER SET 20.00
5TL—12-CUP TEAPOT 13.00 WA1—WARMER 7.50



26 SET— 60.00
RINGED CANNISTER SET

26F—FLOUR, COOKIES, CORN MEAL 20.00 26S—SUGAR 15.00 26C—COFFEE 13.00 26T—TEA 12.00



26G—SUGAR/GREASE 10.00 26H—SALT & PEPPER 7.00
26GH—4-PIECE SET/BOXED 17.00



26DC SET 26.00

26D—1 QT. PITCHER 7.00 26DC—3 OZ. JUICE 3.50
91—TRAY 5.00



5LC SET 26.00

81—1 QT. PITCHER 7.00 5LC—6 OZ. JUICE 3.50
91—TRAY 5.00