


4K—BUTTER DISH
7.00




4F—10" PLATE 6.00

4G—7" PLATE 3.50


4E—5" SAUCER 3.00



*5CC—5 OZ. TEACUP
3.00



*4X—14 OZ. CEREAL
3.50




*5L—12 OZ.
TUMBLER
4.00



*5LC—6 OZ.
JUICE
3.50



4C—CUP
3.50



4Y—6" SPOON HOLDER
4Y - solid colors only
3.50



*4H—SALT & PEPPER
5.00



*4SC—11 OZ. SOUP CUP
4.00



10.00 *4V—2 QT. BAKER/BEAN POT
17.50 *4V/W—BAKER/W WARMER SET



4A—8 OZ. CREAMER
3.50




4B—SUGAR WITH LID
5.50



*4M—18 OZ. MUG
5.00



*4N—24 OZ. VEGETABLE
5.00



*4P—13" PLATTER
8.00



*M2—18 OZ. STEIN
5.00



*224—8" ROUND BOWL
7.00



14.50 *4W—3 QT. BAKER/BEAN POT
22.00 *4W/W—BAKER/W WARMER SET



*4QD—11" DIVIDED BOWL
8.00



*201—9" BOWL
5.00



*242
CORN DISH
3.00



*X0—3 OZ.
SINGLE SERVING BOWL
1.50



*BP—6 OZ. BEAN POT
OR CUSTARD
3.00



*4XL—24 OZ. SALAD
OR GUMBO
4.00



*243—6½" CRESCENT SALAD
3.00



*249 TACO HOLDER
BOXED 2 PER BOX 10.00
Not Available in Flame



*4D—2 QT. PITCHER
10.00

This page available in colors shown on opposite page: except where noted
* Available in all Standard Frankoma Colors & DWTC—Add 50% for Flame
(sizes are approximate and may vary slightly)

Color charts pages 2 & 3