


4K—BUTTER DISH



4F—10" PLATE

4G—7" PLATE

4E—5" SAUCER



*5CC—5 OZ. TEACUP



*4X—14 OZ. CEREAL



*5L—12 OZ. TUMBLER



*5LC—6 OZ. JUICE



4C—CUP



4Y—6" SPOON HOLDER
Solid Colors only-No T.C.



*4H—SALT & PEPPER



*4SC—11 OZ. SOUP CUP



*4V—2 QT. BAKER/BEAN POT
*4V/W—BAKER/W WARMER SET



4A—8 OZ. CREAMER



4B—SUGAR WITH LID

4AB—CREAM & SUGAR SET



*4M—18 OZ. MUG



*4N—24 OZ. VEGETABLE



*4P—13" PLATTER




*M2—18 OZ. STEIN



*224—8" ROUND BOWL



*4W—3 QT. BAKER/BEAN POT
*4W/W—BAKER/W WARMER SET



*4QD—11" DIVIDED BOWL



*201—9" BOWL



*242
CORN DISH
Solid Colors only-No T.C.



*X0—3 OZ.
SINGLE SERVING BOWL



*BP-6 Bean Pot, Custard
or chip-dip- Solid colors
only No Terra Cotta



*4XL—24 OZ. SALAD
OR GUMBO



*243—6½" CRESCENT SALAD



*249 TACO HOLDER
BOXED 2 PER BOX 10.00
Not Available in Flame



*4D—2 QT. PITCHER

This page available in colors shown on opposite page: except where noted
* Available in FRANKOMA COLORS & DWTC - Add 50% for Flame
(sizes are approximate and may vary slightly)

Color charts pages 2 & 3