


\*4K—BUTTER DISH—2.00



6F—10" PLATE—1.80

6G—PLATE 7"—1.00



6B—SUGAR WITH LID—1.50



6A—9 OZ CREAMER—1.00




\*6VT—2½ QT. TUREEN—4.00



6C—CUP—.90

6E—5" WELLED SAUCER—.75



\*6H—SALT & PEPPER—1.50



\*6V—2½ QT. BAKER—4.00



\*5LC—6 OZ. JUICE—.75



\*5L—12 OZ. TUMBLER—.90




\*6CL—DOUBLE COFFEE—1.00



\*81—1 QT. PITCHER—2.00



\*80—2 QT. PITCHER—2.50




\*6VS—1½ QT. BAKER—3.00




\*6T—6 CUP TEA POT—2.50



\*6I—2 CUP TEAPOT—2.00



\*6S—TWO SPOUT GRAVY—2.00



\*5QS—13" STEAK PLATE (SHALLOW PLATTER)—2.00

\*6P—11" STEAK PLATE—1.80

\*5PS—9" TRAY—1.50



\*6U—18 OZ. BAKER-FOR-TWO—2.00  
A COVERED CANDY DISH




\*BP—6 OZ. BEAN POT—.75




6X—14 OZ. CHILI SOUP—1.00


6XS—10 OZ. FRUIT—.80



\*91—10" BAKING DISH—2.00




\*6N—1 QT. BOWL—1.50




\*5P—17" DEEP PLATTER—5.00

\*5Q—13" DEEP PLATTER—2.50



5QD—13" DIVIDED BOWL—2.50



\*TP—17" OVAL PLATTER—5.00