


\*4K—BUTTER DISH—



4F—10" PLATE—

4G—7" PLATE—

4E—5" SAUCER—



4S—6½" BONE DISH—



\*4X—16 OZ. CEREAL—



\*5L—12 OZ. TUMBLER—



\*5LC—6 OZ. JUICE—



4C—CUP—



\*4Y—8" SPOON HOLDER—



4H—SALT & PEPPER—



4A—8 OZ. CREAMER—



4B—SUGAR WITH LID—



4M—18 OZ. MUG—



4Z—6" SOUP—



\*4V—2 QT. BAKER—



4P—13" PLATTER—



4N—24 OZ. VEGETABLE—



\*4W—3 QT. BAKER—



4QD—11" DIVIDED BOWL—




\*214—12" SERVICE BOWL—



\*4SC—11 OZ. SOUP CUP—




\*BP—6 OZ. BEAN POT—



\*231—11" SERVICE BOWL—



4XL—24 OZ. SALAD OR GUMBO—



\*818—5 SECTION LAZY SUZETTE ON BALL BEARING BASE—12"—



4D—2 QT. PITCHER—