


\*4K—BUTTER DISH—2.50



6F—10" PLATE—2.50

6G—7" PLATE—1.25



\*6B—SUGAR WITH LID—2.00



\*6A—9 OZ. CREAMER—1.50




\*6VT—2½ QT. TUREEN—6.00



6C—CUP—1.20

6E—5" WELLED SAUCER—1.20



\*6H—SALT & PEPPER—2.00



\*6V—2½ QT. BAKER—6.00



\*5LC—6 OZ. JUICE—1.00



\*5L—12 OZ. TUMBLER—1.20



\*80—2 QT. PITCHER—4.00



\*81—1 QT. PITCHER—2.50



\*6T—6 CUP TEAPOT—3.50



\*6VS—1½ QT. BAKER—4.50




\*6J—2 CUP TEAPOT—2.50



\*6S—TWO SPOUT GRAVY—2.50



\*6U—18 OZ. BAKER FOR TWO—3.00  
A COVERED CANDY DISH



\*5QS—13" STEAK PLATE (SHALLOW PLATTER)—2.50

\*6P—11" STEAK PLATE—2.00


\*5PS—9" TRAY—1.50



\*BP—6 OZ. BEAN POT  
OR CUSTARD—1.00




6X—14 OZ. CHILI SOUP—1.25  
6XS—10 OZ. FRUIT—1.00



\*91—10" BAKING DISH—2.50




\*6N—1 QT. BOWL—2.00




5P—17" DEEP PLATTER—7.50

5Q—13" DEEP PLATTER—3.50



5QD—13" DIVIDED BOWL—3.50



TP—17" OVAL PLATTER—7.50