




7V—2 QT. BAKER/BEAN POT—4.50



7FL—10" PLATE—2.50  
7F—9" PLATE—2.00  
7G—7" PLATE—1.25  
7E—5" SAUCER—1.20



7D—2 QT. PITCHER—4.00



7W—3 QT. BAKER/BEAN POT—6.00



7B—SUGAR WITH LID—2.00



7A—6 OZ. CREAMER—1.50




7C—CUP—1.20



7M—14 OZ. MUG—1.80



7U—10 OZ. BAKER—2.00



7QS—13" STEAK PLATTER (SHALLOW PLATTER)—2.50



7CL—8 OZ. MUG—1.50




7XO—8 OZ. FRUIT—1.00



7HS—SALT & PEPPER—2.00



7X—14 OZ. CHILI-SOUP—1.25



7K—BUTTER DISH—2.50



7Q—13" DEEP PLATTER—3.50



7XL—20 OZ. SALAD—1.50



7PS—9" TRAY—1.50



7FC—15" CHOP PLATE—10.00



7N—1 QT. VEGETABLE BOWL—2.00



7T—6 CUP TEAPOT—3.50



7P—17" AZTEC OVAL PLATTER—7.50



7I—2 CUP TEAPOT—2.50